


# MAGIC GRIP

## care instructions

Congratulations on your purchase of Magic Grip. We hope you enjoy your new porcelain for many years to come and would like to give you some care instructions.

- *Rinse the items before using them for the first time.*
- *Clean your coated porcelain in the dishwasher or by hand using hot water, detergent and a soft sponge or cloth.*
- *To avoid damaging the silicone coating, do not use a cream cleanser, steel wool, a scrubbing sponge or a strong cleaner.*
- *Avoid contact with solvents, thinners or other chemicals.*
- *Sharp-edged objects can damage the silicone coating.*
- *Keep silicone products away from high heats (transparent silicone foot withstands heat of up to 180°C, black silicone withstands heat of up to 250°C).*
- *Possible consequences of overheating:*
  - *Silicone becomes porous thus reducing the life span of the product.*
  - *Slip resistance and adhesion to the porcelain is affected.*
- *Rinse the porcelain with clean water after coming into contact with chlorinated water or salt water.*
- *Due to the natural properties of silicone, contact with highly colouring foods, constant cleaning in the dishwasher and strong light sources may lead to alterations in the colour and shine of the silicone. These flaws in the appearance of the silicone do not affect the properties of the items.*
- *Avoid prolonged contact with food leftovers.*
- *Signs of wear and tear, such as fine scratches to the surface, do not affect the performance of the coated products.*
- *The silicone coating reacts adversely to soapy or oily surfaces and slipping is increased.*



No slipping.



No scratching.



No clattering.